

1. Introduction

Thank you for your purchase! We appreciate your support.

This document will provide a guide for installation of InSinct CFMoto roll frame accessories.

- K100011 Roll Frame Mounting Clamp



- K100012 Work Light/Aerial Bracket



- K1000013 Roll Frame Clamp Adapter Bracket



- P100075 & P100076 Quick Fist Clamps





Now, to mount your Quick Fist clamp to the adapter bracket, simply use the M5 bolt, washer and nut provided with the Quick Fist clamp. Choose whichever hole you prefer on the adapter bracket, and tighten the Quick Fist mounting bolt to approximately 10N.m.



Place your accessory into the Quick Fist clamp, pull the rubber handle over and onto the tightest possible latching point.

Follow us on our socials to stay up to date with the latest product releases, offroad content and promotions.



[i_n_s_i_n_c_t](https://www.instagram.com/i_n_s_i_n_c_t)



[InSinctOffroad](https://www.youtube.com/InSinctOffroad)



[InSinct](https://www.facebook.com/InSinct)

We love to see what setup our customers come up with, send any photos you'd like to share to stan@insinct.com.au and we will endeavour to post these on our social media platforms.